


AS01 HOP-UP CHAMBER

Operation Manual



- Ares AS01 Stand Hop-up chamber needs to install 3mm steel ball.
- Action Army AS01 Hop-up chamber don't need to install 3mm steel ball.